

PLEASE READ

BEFORE MOUNTING!!

FENDERS TO HOOD

Thank you for purchasing a quality Jones Performance product.

We have included stainless steel bolts to attach your new JP fenders. If you choose to use these bolts you will have to redrill the holes in your O.E. hood, we suggest to redrill at 5/16". If you prefer to use hucks to attach your fenders then no drilling will be necessary.

If you have any questions, suggestions or comments please contact us at 1-800-451-1600.