

PLEASE READ

BEFORE MOUNTING!!

FENDERS TO HOOD

Thank you for purchasing a quality Jones Performance Truk Rodz product.

Alert: Please fit filler panel before painting. Painting before fitting may void your fit warranty.

We recommend fitting with hood already installed on truck.

Mounting Procedure

Step 1: Remove OE upper filler panel mount bracket from cab.

Step 2: Remove JP bracket from JP filler panel and mount this bracket directly to the cab mount.

Step 3: Loosely attach filler panel back to JP bracket and loosely attach lower support rod.

Step 4: Adjust to achieve acceptable gap between hood and filler panel. When acceptable, tighten all bolts.

Step 5: All JP Truk Rodz filler panels have been made long. You may leave as is or trim to your desired length. We recommend the length to be level with the hood or level to the bottom of the cab step.

If you have any questions, suggestions or comments please contact us at
1-800-451-1600.